

## Receipt Printer Installation Instructions

The WashPay Receipt Printer should be centrally located and visible from all wash bays. Since the printer is operator-accessible from the rear, the ideal location would be in the vicinity of the bill changer. The Receipt Printer will be recess-mounted into a pre-cut hole using L-brackets.


Receipt Printer Specifications	
Dimensions, Enclosure	7" W x 16" H x 12.1" D
Dimensions, Front Panel	10" W x 19" H
Weight	29 lbs
Enclosure	Stainless Steel
Power	110-220VAC, 50-60Hz
Wiring	CAT5E Cable



**Important:** The WashPay Receipt Printer enclosures must be connected to earth ground.

Follow the steps below to install the Receipt Printer:

1. Disconnect all power routing to existing equipment.
2. Using the Receipt Printer dimensions shown in the following figure, determine where to mount the Receipt Printer. Make sure the mounting location is a solid surface.
3. Cut a hole for the Receipt Printer in the wall using the dimensions in the following figure.
4. Slide the Receipt Printer into the space you have created in the wall of the building. The back access door will be inside of the building while the printer faces outside.



**Figure 1. WashPay Receipt Printer Dimensions**

